

Engine Identification — New Series

A new system of Engine Identification is being introduced into the various Manufacturing Operations throughout the world, within the Perkins Group of Companies.

This new number consists of up to fifteen letters and numbers which represent:

- Engine Family
- Engine Type and Phase
- Parts List
- Country of Origin
- Production Serial Number
- Year of Manufacturer

Engine Family and Type Codes					
The first two characters are letters, the first of which indicates the engine FAMILY and the second letter is the engine TYPE and PHASE:					
FAMILY	TYPE	CODE	FAMILY	TYPE	CODE
D2.101		A	4.270		N
	D2.101	AA		4.270	NA
				4.300	NB
5/25		B		4.318	NC
	1.18A	BA	6.305		P
	1.18	BB		P6	PA
	1.25A	BC		6.288	PB
	1.36A	BD		6.305	PC
	1.36	BE		PF6.305	PC
	H1.36	BF			
	V2.71	BG	6.247		R
	V2.78A	BH		6.247	RA
	V2.78	BJ			
	V2.95A	BK	6.354		T
	V2.95	BL		6.306	TA
3.152		C		6.335	TB
	P3	CA		6.354	TC
	3.144	CB		H6.354	TD
	P3.144	CC		T6.354	TE
	3.152	CD		HT6.354	TF
	D3.152	CE		6.3541	TG
	G3.152	CF		T6.3541	TH
	P3.152	CG		6.3542	TJ
4.108		E		C6.3542	TK
	4.99	EA		6.3543	TL
	4.107	EB		C6.3543	TM
	T4.107	EC		H6.3543	TN
	4.108	ED		T6.3543	TP
				HT6.3543	TQ
4.154		G		6.372	TR
	4.154	GA		6.3723	TS
4.165		H		TC6.3541	TT
	4.165	HA		T6.3544	TU
				6.3724	TV
				6.3544	TW
4.203		J	6.357		V
	P4	JA		6.357	VA
	4.192	JB		6.3572	VB
	P4.192	JC		C6.3572	VC
	4.203	JD		6.358	VD
	D4.203	JE			
	G4.203	JF	V8.510		X
4.236		L		V8.510	XA
	4.212	LA		TV8.510	XB
	G4.212	LB		V8.540	XC
	4.224	LC		V8.605	XD
	4.236	LD			
	G4.236	LE	V8.640		Z
	4.248	LF		V8.640	ZA
				TV8.640	ZB

Country of Origin Code	
A code, as below, indicates the country in which the basic engine was manufactured.	
A = ARGENTINE	L = ITALY
B = BRAZIL	M = MEXICO
C = AUSTRALIA	N = U.S.A.
D = GERMANY	P = POLAND
E = SPAIN	S = INDIA
F = FRANCE	T = TURKEY
G = GREECE	U = UNITED KINGDOM
H = URUGUAY	X = PERU
J = JAPAN	Y = YUGOSLAVIA
K = KOREA	

Year of Manufacture Code	
The last character indicates the calendar year of manufacture:	
B = 1975	
C = 1976	
D = 1977	
E = 1978	
Etc.	
The letters I, O, Q, R and Z will not be used	

Example of Main Engine Number	
Example TW30016U500256D	
THUS	
T = 6.354 Family	
W = 6.3544 Type	
30016 = Parts List Number	
U = Built in United Kingdom	
500256 = Serial Number	
D = Built in 1977	